+/- 120 DEGREES BETWEEN GUY WIRES

SET ROOT COLLAR 2" TO 3" ABOVE FINISHED GRADE

MULCH 3" DEPTH

COMPLETELY REMOVE BURLAP AND WIRE BASKET FROM TOP ½ OF BALL OR SCARIFIED EXISTING. REMOVE ALL PLASTIC WRAP, FABRIC, ROT PROOF WRAP, FIBER POTS, ETC.

ROTOTILLED SOIL 12" DEEP

TREE ANCHOR AS SPECIFIED

TREE WRAP SECURED WITH TAPE (SEE SPECIFICATIONS)

12" TYP.

36" TYP.

PLANTING MIXTURE AS SPECIFIED

BREAK UP (SCARIFY) SIDES OF PLANTING HOLE

UNDISTURBED SOIL

TREE PLANTING

NO SCALE

MD 329300 001 Tree Planting 7/27/18