



MEDIUM PRESSURE TO LOW PRESSURE STEAM PRV STATION DIAGRAM

NO SCALE

MD 336333 001 2025-XX-XX

DESIGNER NOTES:

1. INDICATED STRAIGHT LENGTHS UPSTREAM AND DOWNSTREAM ARE MINIMUMS. REFER TO MANUFACTURER'S INSTALLATION INSTRUCTIONS FOR MINIMUM REQUIREMENTS.