

KEY NOTES

- 1 CONNECT TO SIDE OF MAIN. PROVIDE ANTI-THERMO SIPHON LOOP. ROUTE PIPING AS SHOWN.
- (2) INSULATE PER SPECIFICATIONS.
- (3) PROVIDE ROOM FOR SCREEN REMOVAL.
- 4 SET PRECHARGE TANK PRESSURE TO ___ PSIG.

- MAKE-UP ASSEMBLY, SEE CLOSED SYSTEM MAKE-UP DETAIL. SET PRV TO__PSIG.
- 6 ESTIMATED SYSTEM VOLUME IS ___GALLONS.
- 7 ROUTE DISCHARGE OF AUTOMATIC AIR VENTS TO FLOOR DRAINS.

COALESCING SEPARATOR AND FLOOR MOUNTED EXPANSION TANK DETAIL

MD 232116 002 2012-11-01